



M459232P

ITEM NUMBER: 459232 & 459242
SERIAL NUMBER: _____

Owner's Manual Electric Stationary Air Compressor (230V, single phase/80 gallon, 5 HP and 7.5 HP)

Instructions for Installation/Set-up, Operation, Maintenance, & Storage

This NorthStar® belt-driven compressor has a 2-stage 3-cylinder pump (Model 459232) or a 2-stage 2-cylinder pump (Model 459242), made with a heavy-duty cast iron cylinders for long life, and a compact design rated for 175 maximum PSI. Its continuous-duty rating ensures long-lasting performance, and its cast iron pump head ensures superior heat dissipation.

Read and understand this Owner's Manual completely before using. Keep this manual for future review. Failure to properly set up, operate and maintain the compressor in accordance with this manual could result in serious injury or death to operator or bystanders.

WARNING: SPECIAL HAZARDS

- **Injection Injury:** High-pressure air stream can pierce skin and underlying tissues, leading to serious injury and possible amputation. Such an injection injury can result in blood poisoning and/or severe tissue damage.
- **Flying Debris:** High-pressure air stream can cause flying debris and possible surface damage.
- **Not For Breathing Air:** NorthStar compressors are NOT designed, intended, or approved for supplying breathing air. No compressed air should be used for breathing unless air is treated in accordance with applicable standards.
- **Fire/Explosion:** Sparks from air powered tool heads or attachments can ignite fuel or other flammable liquids or vapors in the vicinity. Exceeding the maximum pressure for air tools or attachments could cause them to explode. Always keep a fire extinguisher rated "ABC" nearby.
- **Burns:** Compressor pump, motor and discharge tubing are hot surfaces that can cause burn injuries.
- **Electric Shock:** Operating equipment in wet conditions or where not properly grounded can cause electric shock.

Detailed safety information about these hazards appears throughout this manual.

Equipment Protection Quick Facts

Inspect Upon Delivery: FIRST! Inspect for missing or damaged components. See "Initial Set-Up" section for where to report missing or damaged parts.

Electrical Service: Only connect unit to a 230V line with adequate line amperage (30A for 459232, 40A for 459242). Do not connect air compressor to a 208V 3-phase system. A 208V system can provide low voltage and damage the air compressor. When installing the air compressor, one must check that the voltage at the terminal is no lower than 208V.

Check Pump Oil: Pump is shipped with oil. Check the pump oil level before starting. See "Preparing for Operation" section of this Owner's Manual for capacity and viscosity.

Use Mechanical Lifting Equipment: Compressor is shipped on a pallet and is too heavy to handle manually. Use proper lifting equipment for unloading and moving to installation site.

Install Using a Qualified Electrician: All wiring, grounding, and electrical connections must be made by a qualified electrician. Install according to local and national codes.

Install a Regulator: We recommend installing a regulator on the compressor at each distribution point to maintain constant pressure in the outlet hose line and provide reduced pressure appropriate for air tool being used.

Run Pump Unloaded for Break-in Period: Before initial use, open ball valve and run compressor for 30 minutes to break in pump parts.

Follow Maintenance Schedule: Pump, air filter, and tank require periodic inspection and servicing to provide efficient function and long life. See "Maintenance Schedule" for frequency of servicing.

Table of Contents

Equipment Protection Quick Facts	1
Table of Contents	2
About Your Air Compressor	4
Specifications	5
Component Identification	6
Safety Signal Words	7
Hazard Signal Word Definitions	7
Safety Labeling	8
Safety Decal Locations	8
Safety Decals	9
.....	9
Initial Set-Up	10
Step 1. Inspect & Unpack	10
Step 2. Assembly	10
Attach Air Filter (Model 459242 Only)	10
Attach Regulator (Recommended)	10
Step 3. Select Suitable Location	11
Step 4. Permanent Mounting	11
Step 5. Installing Distribution Piping	12
Step 6. Wiring Installation	12
Electric Compatibility	12
Wire Size	12
Circuit Breaker	13
Grounding	13
Model #459232 (230 Volt; 5 HP)	14
Model #459242 (230 Volt; 7.5 HP)	14
Operation	15
Follow Operation Safety Rules	15
Prepare for Operation	15
Check/Add Oil to the Pump	15
Proper Air Hose and Tool Use	16
Pressure Control Related Devices	16
Compressor - Tool Requirements	16
Attaching/Disconnecting Air Hose and Tools	16
Using Compressor for Spraying	17
Flammable Materials	17
Moisture in Compressed Air	17
Shutdown	17
Procedure	17
For Malfunction During Operation	17
Maintenance & Repair	18
Maintenance Schedule Summary	18
Detailed Instructions – Maintenance & Repair	18
Inspect Safety/Relief Valve	18
Inspect Air Filter	18
Keep Compressor Clean	18

Inspect Compressor for Air Leaks	19
Change Pump Oil.....	19
Drain Receiver Tank and Inspect Tank.....	19
Check Drive Belt for Tension and Alignment.....	19
Keep Compressor Clean.....	20
Troubleshooting	21
Parts Explosions – Model 459232 & 459242 Rev P	22
Parts List – Model 459232 & 459242 Rev P.....	23
459232 Pump Explosion	24
459232 Pump Parts List	25
459232 Pump Kits.....	26
459232 Pneumatic Schematic.....	27
459242 Pump Explosion	28
459242 Pump Parts List	29
459242 Pump Kits.....	30
459242 Pneumatic Schematic.....	31
Appendix A: Lubricants and Compatibility	32
Alternate Lubricants	32
Limited Warranty	33
California Proposition 65 Information	34

About Your Air Compressor

Thank you for purchasing a NorthStar air compressor! It is designed for long life, dependability, and top performance.

Intended Use. Provides compressed air used primarily for operating air tools and pressurizing other objects that require high air pressure, such as tires. Do not use for low-pressure objects such as balloons, air mattresses, and sport balls, which can explode quickly and easily. Special precautions are necessary when used for cleaning to prevent flying debris hazards. It is not to be used to supply breathing air.

Supplies Required. Normal operation will require you to supply:

- Pressure regulator (recommended)
- Pump oil
- Personal protection equipment

See “*Specifications*” section for more detail.

Site Location. Intended for indoor use.

Personal Protection. Wear safety apparel during operation, including safety glasses with side and top protection.

Adult Control Only. Only trained adults should set up and operate the air compressor. Do not let children operate.

Under The Influence. Never operate, or let anyone else operate, the air compressor while fatigued or under the influence of alcohol, drugs, or medication.

Keep this manual for reference and review.

ATTENTION: Rental Companies and Private Owners who loan this equipment to others!


All persons to whom you rent/loan this air compressor must have access to and read this Owner's Manual. Keep this manual with the air compressor at all times and advise all persons who will operate the machine to read it. You must also provide personal instruction on how to safely set-up and operate the air compressor and remain available to answer any questions a renter/borrower might have. Owner's Manuals are available from NorthStar at 1-800-270-0810.

For any questions, comments, problems or part orders, call Northern Tool at 1-800-221-0516.

Specifications

MODEL		
Model #	459232	459242
FLOW OUTPUT		
Max. Pressure Rating	175 PSI	175 PSI
Volume Rating @ 90PSI	14.9 CFM	24.4 CFM
Receiver Capacity	80 gal.	80 gal.
POWER REQUIREMENTS		
Dedicated NEMA Receptacles	6-30R	6-50R
Volts	230V	230V
Amps	30A	40A
MOTOR		
Horsepower	5 HP	7.5 HP
DIMENSIONS / COMPONENTS		
Length	25"	25"
Width	33"	33"
Height	68"	69"
Weight	409 lbs.	537 lbs.
Mounting Hole Diameter	.56"	.56"
Suggested Mount Bolt Diameter	7/16"	7/16"
SUPPLIES REQUIRED (not included)		
Pump Oil (shipped with oil, but refills required)	SAE 30 non-detergent pump oil (#4043)	SAE 30 non-detergent pump oil (#4043)
Pump Oil Capacity	27 oz.	33.8 oz.
OTHER		
Certifications:	California 462 (L) (2) Compliant	California 462 (L) (2) Compliant

Component Identification



1. **Lifting Eyes:** May also be used as tie down locations.
2. **Ball Valve:** On/Off control for pressurized air supply from receiver tank (not the output pressure). A regulator and/or quick connect fittings can attach to its ½" NPT outlet. A regulator should be installed for pressure regulation purposes.
3. **Pressure Gauge:** Air filled gauge. Shows pressure in receiver tank.
4. **Air Receiver / Storage Tank:** 80 gallon ASME certified tank.
5. **Discharge Tube:** Carries compressed air from pump to safety/check valve, and then to the storage tank. It becomes very hot during use and can cause severe burns. Never touch.
6. **Pressure Switch-Auto/Off switch:** In AUTO position, compressor shuts off automatically when tank pressure reaches maximum preset pressure (approximately 175 PSI). In OFF position, compressor will not operate. Switch should be in OFF position when connecting or disconnecting power cord from electrical outlet. NEVER attempt to adjust this pressure switch.
7. **Tank Drain Valve:** Used to remove moisture from air after compressor is shut off and air emptied from tank. Drain moisture daily after each use.
8. **ASME Safety/Check Valve:** Automatically releases air if tank exceeds preset pressure max. of 200 PSI. A check valve is a pressure release port. Pull valve pin to relieve pressure from receiver tank.
9. **Unloader:** Vents discharge air to atmosphere in start/stop operation.
10. **Air Compressor Pump:** Shipped with oil.
11. **Belt Guard:** Covers belt, engine pulley and flywheel. NEVER operate compressor without belt guard in place.
12. **Compressor Air Filter:** Keep clean and particle free. See "Pump Explosion and Pump Parts List" for replacement part number.
13. **Magnetic Oil Drain Plug:** Removal allows for drainage of oil from pump. Attracts metal particles that could damage pump.

Safety Signal Words

Hazard Signal Word Definitions



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



DANGER (red) indicates a hazardous situation, which if not avoided, will result in death or serious injury.



WARNING (orange) indicates a hazardous situation, which if not avoided, could result in death or serious injury.



CAUTION (yellow), used with the safety alert symbol, indicates a hazardous situation, which if not avoided, could result in minor or moderate injury.



CAUTION (yellow), without the safety alert symbol, is used to address practices not related to personal injury.




NOTICE is used to address practices not related to personal injury.

Safety Labeling

Safety Decal Locations

⚠ WARNING:

ALWAYS make sure safety labels are in place and in good condition. If a safety label is missing or not legible, order new labels from NorthStar Product Support at 1-800-270-0810.



On-Product Warning Labels


Location	Part numbers	Description
1	788998	Air Compressor Instructions
2	788924	Air Compressor Safety
3	789060	Electrical Shock Hazard
4	798206	California 462 (L) (2) Compliance

Safety Decals

1

<p>MAINTENANCE SCHEDULE Read Owner's Manual for details.</p> <p>DAILY: 1. Check oil level in pump. 2. Depressurize air tank and drain water.</p> <p>WEEKLY: 1. Inspect air filter element; clean if necessary. 2. Clean all external parts. 3. Test safety valve by pulling ring. Replace if valve does not operate freely.</p> <p>MONTHLY: 1. Check for air leaks. 2. Inspect bolts and screws; tighten as needed. 3. Check belt for tension and wear; replace as needed.</p> <p>Pump Oil: Change first 50 hours, then every 500 hours.</p> <p><small>For questions, replacement parts or labels contact product support at www.northerntool.com or call 1-800-270-0810.</small></p>	<p>OPERATING INSTRUCTIONS</p> <p>BEFORE STARTING</p> <ol style="list-style-type: none"> 1. Read Owner's Manual for details. 2. Always wear ear protection and ANSI Z87.1 approved safety glasses with side shields. <p>STARTING INSTRUCTIONS</p> <ol style="list-style-type: none"> 1. Toggle on-off switch to ON position. <p>SHUT DOWN</p> <ol style="list-style-type: none"> 1. Toggle on-off switch to OFF position. 2. Depressurize air tank by pulling ring on safety valve. 3. Drain water by opening drain on tank.
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

2

! WARNING	
	<p>Burn Hazard</p> <p>Hot pump - Do not touch. Pump may be hot even if the unit is stopped.</p> <p>Allow unit to cool before servicing.</p>




3

! WARNING	
	<p>Electrical Shock Hazard</p> <ol style="list-style-type: none"> 1. Stationary units are intended to be permanently connected to a grounded circuit by a qualified electrician. 2. Improper electrical grounding can result in serious injury or death from electrocution. 3. Disconnect and lockout from power sources before servicing.

! WARNING	
	<p>Belt Entanglement Hazard</p> <p>KEEP belt guard in place while machine is operating.</p>

4

**CALIFORNIA
462 (L) (2) COMPLIANCE**

! WARNING	
	<p>Corrosion Bursting Hazard</p> <p>Depressurize air tank and drain water daily after use. Rusted air tanks can rupture or explode and cause severe injury or death.</p>

! DANGER	
<p>Breathing Air Hazard</p> <p>NorthStar air compressors are NOT designed to supply breathing air.</p> <p>NEVER breathe compressed air. It can contain carbon monoxide (CO) or other contaminants which may cause serious injury or death.</p>	

Initial Set-Up

Step 1. Inspect & Unpack

Upon receipt, inspect air compressor for missing or damaged parts. Verify that it is the compressor you ordered.

See “*Component Identification*” section of this manual for a diagram of the compressor and its components.

- For missing or damaged components, please contact Product Support at 1-800-270-0810.
- If complete, fill out product serial number information. See “*Limited Warranty*” section of this manual.

Step 2. Assembly

Attach Air Filter (Model 459242 Only)

1. Remove air filter from manual bag.
2. Remove plastic plug from air compressor inlet. (Figure 1)




Figure 1

3. Unscrew wing nut, remove washer and air filter housing from base. (Figure 2)




Figure 2

4. Screw base into air compressor inlet as shown. Tighten with appropriate tool on specified location. (Figure 3 & Figure 4)




Figure 3




Figure 4

5. Replace air filter housing and washer. Secure with wing nut, hand tighten only. (Figure 5)




Figure 5

Attach Regulator (Recommended)

We recommend using a regulator with this compressor since the pre-set tank pressure ranges between 145 and 175 PSI and is usually greater than what is needed by tools.

Without the addition of a regulator, the pressure switch will maintain a tank pressure within the pre-set range that has a max of 175 PSI. This is considered an overly high pressure for many tools. A user-installed regulator can maintain a lower constant pressure in the outlet hose line and prevent over pressurization of tools.

⚠️ WARNING: Bursting hazard

Too much air pressure causes a hazardous risk of bursting. Check the manufacturer's maximum pressure rating for air tools and accessories. Regulators must never be set to exceed the maximum pressure rating of tank or tools.

Step 3. Select Suitable Location

⚠ WARNING: Lifting hazard

The compressor is heavy. Ensure that proper lifting equipment is available to unload and move compressor to installation site.

Location Criteria:

- Location must be inside an enclosed building
- Where no flammable vapors, dusts, and gases are present.
- At least 15" away from walls and other objects.
- Away from other heat-generating equipment.
- Away from dusty/dirty conditions.
- In a well illuminated area.
- Where proper wire size is already, or can be made, available.

Positioning:

- The compressor should be mounted on a dry, firm, and level surface. It must sit level and be stabilized since it will slide or shift during operation if not secured.

Airflow:

- Provide access to adequate, clean and unobstructed airflow for cooling and air supply.
- Remember the supply air is passing through the compressor supply hoses and tools. These can be damaged or have a shortened life if unclean air is present or air filter is not clean and functioning properly.
- Do not allow debris to accumulate or block airflow.
- Do not operate with a tarp, blanket, or cover surrounding the machine, which blocks air flow.
- Do not place any objects against or on top of the unit, which can also block airflow or damage unit.

Electrical:

- MUST be connected to a 230 Volt, single-phase outlet having operating capacity of 30 amps (Model #459231, 5 H.P.) or 40 amps (Model #459241, 7.5 H.P.).

Wiring:

- Proper wire size should take into consideration length from distribution panel.
- See Step 6, "Wiring Installation" for more information.

Ideal operating temperatures:

- 40° and 100°F (4° and 37°C).

Operating Limitations:

- 15°F (-9°C) or above 125°F (52°C).

If temperatures consistently drop below 32° F (0°C), install within a heated building. If this is not possible, protect the safety/relief and drain valves from freezing.

Note: Excessive moisture is likely to occur if unit is stored in an unheated area subject to large temperature changes. Moisture forming in pump can produce sludge in the oil, causing parts to wear out prematurely. Excessive condensation on the pump when it cools down is a sign that this may be occurring.

Step 4. Permanent Mounting

You will permanently mount the compressor after selecting the location in Step 3.

1. On a concrete pad or other stable mounting platform, drill 4 holes according to the mounting dimensions given in the diagram below. (Figure 6)




Figure 6

2. Unbolt the compressor feet by removing the bolts, washers and nuts. Discard them after removal. (Figure 7)




Figure 7

3. Lift and remove the compressor from the pallet using a hoist and lifting eyes provided.
4. Situate unit in chosen location and bolt in place. (Use 7/16" bolts and washers. Make sure bolts are long enough to provide a good anchor point.) Bolt it in place to prevent unit from vibrating excessively. Use metal shims under the "short" feet if necessary.

- A rubber isolation mat or pads may be used under each mounting foot to reduce vibration.

Step 5. Installing Distribution Piping

The stationary compressor can utilize the same type of properly rated, single flexible hose, as is used on portable air compressors. However, many purchasers will prefer to utilize the stationary unit through a permanently installed distribution system serving several points within a facility. The design, installation and usage of stationary compressed air distribution systems has been the subject of extensive industrial, trade and government attention, as can be seen within many private and government websites.

An example of the typical components used in a permanent distribution system are shown in Figure 8.




Figure 8

It should be obvious that there is considerable complexity in designing and installing such a system. Controlling the pressures, moisture in the air, drying components, contaminants, lubrication, as well as choosing and sizing the piping for the system, requires the expertise of persons or firms familiar with such designs and their installation.

A very significant safety issue arises when one is distributing line pressure air throughout a facility, which is over 150 PSI. Standard components, steel pipe fittings and many plastic compressed air piping systems are only rated to 150 PSI and cannot be safely used in such distribution systems. In such cases, immediately regulating the distribution line pressure at the compressor outlet to under 150 PSI (usually in the 90-

120 PSI range) is mandatory for many compressed air piping systems.

Northern Tool recommends that you contact plumbers or mechanical contractors with expertise in compressed air systems to plan and/or install your distribution system.

⚠ WARNING: Bursting hazard

This unit can produce pressures in excess of 150 PSI, which is beyond the capabilities of many piping types and pipe fittings. Failure of undersized and/or inadequate distribution components can lead to serious injury.

⚠ WARNING: Restriction hazard

If an aftercooler, check valve, block valve, or any other restriction is added to the compressor discharge, install a properly sized ASME approved pressure safety/relief valve between the compressor discharge and the restriction.

Step 6. Wiring Installation

Wiring should be installed by a qualified electrician. Installations must be in accordance with all applicable local, state, and federal regulations.

⚠ WARNING: Electrical Shock Hazard

Improper electrical grounding can result in a risk of electric shock. Electrical installation and service of the 230V, single-phase box (30 or 40 amp) MUST be made by a qualified electrician. If the compressor must be reinstalled at a different location, the re-connection should also be made by qualified personnel. The compressor motor may not start or may burn out prematurely if adequate amperage or voltage is not available.

Electric Compatibility

The motor rating, as shown on the motor nameplate and the building power supply must have compatible voltage, phase and hertz characteristics.

Wire Size

The electrical wiring required between the building's power supply and the electric motor varies according to motor horsepower. Power leads must be adequately sized to protect against excessive voltage drop during start-up. High voltage drops can cause motor to overheat and fail. A qualified electrician should provide information for selecting proper wire size. If other electrical equipment is connected to the same circuit, the total electrical load must be considered in selecting the proper wire size. DO NOT use undersized wire.

⚠ CAUTION: Inadequate wiring hazard

Overheating, short-circuiting and fire damage will result from inadequate wire sizing.

Circuit Breaker

Your electrician will need to refer to the National Electric Code to determine the proper circuit breaker rating required. When selecting a circuit breaker, remember the momentary starting current of an electric motor is greater than its full load current. Time-delay or “slow-blow” circuit breakers are recommended.

Grounding

This product and its associated conduit and junction box must be grounded. Do not ground to a gas supply line.

⚠ WARNING: Electrical shock hazard

Improperly grounded motors are shock hazards. Make sure all equipment is properly grounded. Check with a qualified electrician if you are in doubt as to whether the outlet is properly grounded.

Model #459232 (230 Volt; 5 HP)

You will recognize this unit since it has a motor reset button. The power lines can be connected directly to the pressure switch (Figure 9). The connections on L1 and L2 must be torqued to 17.7 Lbf-in (2 Nm). This unit must be connected to a 230V circuit with a minimum rating of 30 amps. Do not use this unit on a 208V circuit of any kind.

Model 459232 Front View - Pressure Switch




Figure 9




Figure 10

Model #459242 (230 Volt; 7.5 HP)

This unit has a motor starter. Connect power lines to the starter on L1 and L2 as shown in Figure 11. The connections on L1 and L2 must be torqued to 36-44 LBF-in (4.1-5 Nm). This unit must be connected to a 230V circuit with a minimum rating of 40 amps. Do not use this unit on a 208V circuit of any kind.

Note: For this model, do NOT connect the power line to the pressure switch. The motor will not start and will be damaged.

Model 459242 Side View - Motor Starter




Figure 11




Figure 12

Operation

Follow Operation Safety Rules

Before starting the compressor, review the safety rules found below and throughout the manual.

WARNING

Failure to follow safety rules may result in serious injury or death to the operator or bystanders.

Instruct Operators. Owner must instruct all operators in safe set-up and operation. Do not allow anyone to operate the compressor who has not read the Owner's Manual.

Safety Guarding. Only operate with safety covers, guards and barriers secured and in good working order.

Moving Parts. Keep hands, feet, hair and apparel away from moving parts. Never remove any guards while the unit is operating. Do not reach into an air vent or cavity, as they may cover dangerous moving parts.

Ear Protection. Hearing can be damaged from prolonged, close-range exposure to the noise level produced by this compressor. Ear plugs or other hearing protection is recommended for persons working who are exposed within 15-20 feet of the running compressor for an extended period of time.

Eye Protection. Wear ANSI/OSHA required "Z87.1" safety glasses when operating or servicing the compressor. Pressurized air spray from this unit can cause severe injury to the eyes. Also, small objects will become airborne as the air spray contacts them.

Respirator. Wear a respirator when using the compressed air for spraying. Spray in a well-ventilated area to prevent health and fire hazards.

Prepare for Operation

Make sure that any regular maintenance has been performed as prescribed in "Maintenance & Repair" section.

- Refer to the engine Owner's Manual for engine maintenance instructions.
- Drain receiver tank of any moisture.
- Inspect for oil leaks.
- Check for any unusual noise/vibration.
- Ensure the area around compressor is free from rags, tools, debris and flammable or explosive materials.

- Ensure belt guards and covers are securely in place.

WARNING: Entanglement hazard

Do NOT operate with protective covers or guards removed. Beneath these covers are high speed moving components, which can entangle the operator or bystanders. Entanglement in this equipment may result in serious injury, amputation or death.

Check/Add Oil to the Pump

Check the oil level in the pump. Use sight glass for pump oil level. Add oil as needed.

Engine: See engine Owner's Manual for capacity and recommended oil type for your expected ambient conditions.

WARNING: Burn hazard

Never open oil port while compressor is running. Hot oil can spray over face and body.

CAUTION: Inadequate lubrication hazard

Never operate compressor with inadequate lubricant. This will cause overheating and severe damage to the engine and pump.




Figure 13

459232 Model Pump: The compressor pump capacity is 27 oz. Use SAE 30 non-detergent pump oil (part #35605) prior to break-in. You may use synthetic lubricants after 50 hour break-in. See "Lubricants and Compatibility" for a list of suitable and alternative lubricants.




Figure 14

Pump: The compressor pump capacity for Model 459242 is 33.8 oz. Use SAE 30 non-detergent pump oil (part #4043) prior to break-in. You may use synthetic lubricants after 50 hour break-in. See “Appendix A: Lubricants and Compatibility” for a list of suitable and alternative lubricants.

CAUTION: Synthetic lubrication damage

If you will be using a synthetic lubricant, all downstream piping material and system components must be compatible.

Start-Up Procedures

CAUTION: Break-in period

Before initial use, open the ball valve and run the compressor without air tools attached and through open air line for 30 minutes to break-in pump parts.

1. Verify that the pressure switch is in the OFF position. (Figure 15)




Figure 15

2. Turn regulator counter clockwise to close, if installed.
3. Verify that the pressure gauge reads zero.
4. Open the ball valve so that air flow is permitted.
5. Turn the pressure switch to the AUTO position.
6. Adjust regulator to desired pressure, if installed.
7. Allow pressure in receiver tank to build.

Note: This electric model is equipped with a pressure switch that automatically turns the motor off when the tank pressure reaches its present level. Once air pressure in the tank drops to a preset low level, the pressure switch automatically turns the motor back on.

WARNING: Overheating

This compressor is equipped with “auto shut off”. However, failure to allow adequate cooling ventilation or a restriction in the intake airflow may cause the machine to overheat.

WARNING: Inflatables/Low PSI tire

Never use compressor to inflate small low-pressure objects, i.e., balloons/inflatables, small or low volume PSI tires. It is easy to over-pressurize them, causing them to rupture. Identify the inflation capacity of an object prior to filling it with air. Use a gauge to check the pressure regularly when inflating anything.

**Proper Air Hose and Tool Use
Pressure Control Related Devices**

Never remove, adjust, bypass, change, modify or make substitutions for safety/relief valves, pressure switches or other pressure control related devices. Pressurizing beyond the limits of the compressor could result in an explosion.

WARNING: Overpressurization hazard

NEVER over-pressurize the receiver tank or air tools beyond nameplate capacity. Exceeding the pressure rating could cause them to explode or fly apart.

Compressor - Tool Requirements

- Compressor and attachments must be sized properly for pressure and air volume.
- Consider the maximum pressure requirements and air volume requirements of each. (The volume rating of your compressor is listed in the “Specifications” section.)

CAUTION: Tool overpressure hazard

Do not operate this unit with any tool rated less than the maximum operating pressure of the unit (175 PSI) unless a properly sized regulator limiting pressure is used before the tool.

Attaching/Disconnecting Air Hose and Tools

CAUTION: High pressure stream hazard

High-pressure air stream can pierce skin and underlying tissues, leading to serious injury and possible amputation. Such an injection injury can result in blood poisoning and/or severe tissue damage. High-pressure air stream can also cause flying debris and possible surface damage.

On a fixed line distribution system the flexible hosing and tools would typically be connected at a terminating

point. In some cases where a fixed system does not exist, the flexible hosing can be attached to the quick connect fitting on the main compressor outlet or after the user installed regulator.

⚠ CAUTION: Air tools hazard
Do not attach air tools to open end of the hose until start-up is completed and the unit checks out OK.

Quick Connect Procedure:

- Keep finger off tool or activation switch until ready to use.
- Pull quick connect collar back (Figure 16a).
- Push hose or attachment firmly against stop.
- Let go of collar (Figure 16a).
- Pull and rotate slightly (hose or attachment) to assure a tight connection.

⚠ WARNING: Projectile hazard
Air tool or attachment can become a projectile and cause serious personal injury or damage if not securely attached to the air hose.





Figure 16b




Figure 16c

Using Compressor for Spraying Flammable Materials

Always follow precautions on container labels or MSDS' before spraying flammable materials, such as paint.

Moisture in Compressed Air

Moisture in supply air when compressed will form into droplets as it leaves air compressor pump and enters receiver tank. When humidity is high or when a compressor is in continuous use for an extended period of time, a significant amount of moisture will collect in

the tank. Part of the moisture will be discharged in the outlet air.

When using a paint spray or sandblast gun, this water will be carried from the tank through the hose, and out of the gun as droplets mixed with the spray material. If this is not acceptable for your application, an external air dryer must be added to the system.

Shutdown

Procedure

When you are finished using the compressor:

1. Move the pressure switch to the OFF position.
2. Close the ball valve to stop airflow.
3. Unplug the power cord.
4. Operate tools briefly to release live pressure
5. Disconnect all tools.
6. Drain air receiver tank by pulling safety relief valve.
7. After all storage air is discharged, disconnect hoses and open the ball valve.
8. Once the tank pressure gauge registers under 10 PSI, open the drain valve on the bottom of the tank to drain condensation moisture.

⚠ WARNING: Risk of bursting
Drain air receiver tank daily or after each use to prevent moisture buildup in the air tank. Serious injury or death may occur from a tank explosion caused by moisture induced tank corrosion.

For Malfunction During Operation

Immediately turn off the compressor if any of the following conditions arise during operation:

- Excessive change in motor speed, slow or fast
- Overheating
- Excessive vibration
- Unusual noise
- Flame or smoke
- Air leakage

Pull ring on safety valve to immediately relieve pressure.

⚠ WARNING: Shutdown hazards
Do not leave an operating machine unattended. Always shut the machine OFF and relieve the pressure before leaving the machine. NEVER disconnect the high-pressure outlet hose from the unit while the tank and airline are pressurized. A hazardous high pressure air stream will result as receiver tank is quickly emptied.

Maintenance & Repair

⚠ WARNING: Maintenance hazards

ALWAYS disconnect, lock out and tag the main power supply and then release air pressure from the receiver tank before cleaning, adjusting, or servicing the compressor. Make sure all guards and shields are replaced before re-starting.

Maintenance Schedule Summary

Item	Frequency
Inspect safety/relief valves	Weekly
Check pump oil level	Weekly
Inspect air filter	<ul style="list-style-type: none"> Weekly Replace every 12 months or 1000 hours of use
Inspect for air leaks	Monthly
Change pump oil/ Clean magnetic drain plug	<ul style="list-style-type: none"> After first 50 hours of use Every 3 months or 500 hours of use
Inspect & drain receiver tank	Daily
Check drive belt tension and alignment	Monthly
Dust/debris removal	Monthly

See detailed instructions for each maintenance item below.

Detailed Instructions – Maintenance & Repair

NOTICE

Dispose of used motor and pump oil in a manner that is compatible with the environment and in accordance with local, state, and federal laws and regulations.

- Take used oil in a sealed container to your local recycling center or service station for reclamation.
- Do not throw it in the trash, pour it on the ground, or pour it down a drain.

No Modifications. Never modify or alter the compressor in any way. Modifications can create serious safety hazards and will void the warranty.

Inspect Safety/Relief Valve

This valve should be inspected and tested on a weekly basis. The safety valve automatically releases air if the tank pressure exceeds the preset maximum.

- Check the safety/relief valve by pulling the rings. It is spring loaded and should not be stuck but come out about 1/4" and then snap back into position when released.
- Replace safety/relief valves that do not operate freely with a valve of the same pressure rating.

⚠ WARNING: Safety/Relief valve hazards

If the safety/relief valve does not work properly, over-pressurization may occur causing air tank rupture or explosion. Occasionally pull the ring on the safety valve to make sure the safety valve operates freely. If the valve is stuck or does not operate smoothly, it must be replaced with a valve having the same pressure rating.

Inspect Air Filter

Inspect the compressor's air filter on a weekly basis. A dirty air filter will not allow the air compressor to operate at full capacity.

- Clean air filter if dirty and restricted air flow.
- Replace the air filter every 12 months or 1000 hours.

Note: Do not operate with the air filter removed.

Keep Compressor Clean

Do not allow air intakes to become blocked. If dust or debris accumulates in the compressor, clean with a damp cloth or soft bristle brush.

Note: Do not spray compressor with a garden hose or pressure washer. Water may enter the compressor and cause damage to the motor and pump.

Inspect Compressor for Air Leaks

Inspect system for air leaks on a monthly basis. To test:

- Squirt soapy water around joints during compressor operation and watch for bubbles. Developing bubbles indicate a leak is present.
- Tighten fittings, if necessary.

Change Pump Oil

⚠ WARNING: Burn hazard

Never open oil fill port while compressor is running. Hot oil can spray over face and body.

After the first 50 hours of use then every 3 months or 500 hours, change pump oil while crankcase is still warm. (See "Appendix A: Lubricants" for suitable alternatives.)

1. Remove the oil fill and drain plugs. Collect the oil in a suitable container.
2. Replace the oil drain plug and refill compressor crankcase with clean oil.
3. Replace the oil fill plug.
4. Start the unit and run for several minutes. Shut down the air compressor and recheck the oil level. If necessary, add more oil. (Figure 17)




Figure 17

Drain Receiver Tank and Inspect Tank

Drain water from the receiver tank daily. Water left in the tank can cause the tank to weaken and corrode, increasing the risk of tank rupture. Badly rested receiver tanks must be replaced.

Northern Tool recommends a tank inspection after every 2 years of service. See "Inspection of Unfired Pressure Vessels," volumes 2-9, August 2001, Bill McStaw (available on-line at NTIS)."

⚠ WARNING: Air tank hazards

Failure to replace a rusted air receiver tank will eventually result in tank rupture or explosion, which could cause substantial property damage, severe personal injury, or death. Never modify or repair a tank. Obtain replacement from service center.

Check Drive Belt for Tension and Alignment

⚠ CAUTION: Pulley/sheave hazard

Improper pulley/sheave alignment and belt tension can result in motor overload, excessive vibration and premature belt and/or bearing failure. To prevent this from happening, check the pulley/sheave alignment and belt tension on a regular basis.

Belts will stretch from normal use. When properly adjusted, a 5 lb. force applied to the belt between the motor pulley and the pump will deflect the belt about 1/2".

To align and adjust drive belt tension:

1. Remove the belt guard cover.
2. Loosen the four fasteners securing the motor to the compressor unit.
3. Slide the motor to achieve proper belt tension. (Usually 1/8" to 1/4" is sufficient.) The belt must be properly aligned before refastening the motor.
4. To align belt, lay a straight edge against the face of the compressor sheave (flywheel) touching the rim at two places. (Figure 18)




Figure 18

5. Adjust the motor pulley by shifting the motor so that the belt runs parallel to the straight edge.
6. If necessary, use a gear puller to move the motor pulley. Tighten set screw after motor pulley is positioned.
7. Check for proper belt tension. (Figure 19)




Figure 19

8. Tighten the four fasteners holding the motor to the top plate while tension and alignment is maintained.
9. Attach the belt guard cover.

00882

Keep Compressor Clean

Do not allow air intakes to become blocked. If dust or debris accumulates in the compressor, clean the compressor with a damp cloth or soft bristle brush.

Note: Do not spray compressor with a garden hose or pressure washer. Water may enter the compressor and cause damage to the engine and pump.

IMPORTANT

If a part needs replacement, only use parts that meet the manufacturer's part number specifications. Replacement parts that do not meet specifications may result in a safety hazard or poor operation of the compressor. Major service, including installation or replacement of parts, should be made by a qualified electrical service technician.

Contact NorthStar Product Support at 1-800-270-0810

for any questions, problems, or parts orders.

Troubleshooting

This section provides a list of the more frequently encountered compressor malfunctions, their causes and corrective actions. Some corrective actions can be performed by the operator or maintenance personnel, but others may require assistance of a qualified electrician or Service Center.

PROBLEM	POSSIBLE CAUSE
Motor does not turn.	A,B,C,D,E
Motor overload trips or draws excessive current.	D, G, M
Excessive noise, vibration, knocking or rattling.	H, I, K, L,N, O, P, R, W
Lights flicker or dim when running.	C, D, E, J, M
Air delivery drops off.	I, J, L, M, N, O, P, R, W, X, Y
Compressor does not come up to speed.	C, D, F, H, L, M, P
Compressor is slow to come up to speed.	C, D, F, H, L, M, N
Compressor will not unload cycle.	I, N, P, R
Compressor will not unload when stopped.	I, N, P, R
Excessive starting or stopping.	D, E, G, P, S, U
Moisture in crankcase, "milky" substance in oil.	T
Oil in discharge air.	V
Safety/relief valve "pops".	N, O, P
Low interstage pressure.	Y
High interstage pressure.	X

POSSIBLE CAUSE	POSSIBLE SOLUTION
A.) Circuit breaker on motor tripped.	Push button located on back of motor.
B.) Supply line circuit breaker tripped.	Reset circuit breaker.
C.) Wiring or electric service panel too small.	Install properly sized wire or service box. Contact electrician.
D.) Compressor wired incorrectly.	Check wiring, contact electrician.
E.) Poor contact on motor terminals or starter connections.	Ensure good contact on motor terminals or starter connections.
F.) Compressor viscosity too high for ambient temperature	Drain existing lubricant and refill with proper lubricant.
G) Poor ground.	Check all ground connections.
H.) Belt tension too tight or sheaves not aligned	Check tension/ alignment.
i.) Air leaks in discharge piping	Check tubing connections, Tighten joints or replace as required.
J.) Poor power regulation	Contact power company.
K.) Compressor components leaky, broken, loose	Inspect components. Clean or replace as required.
L.) Loose flywheel or motor pulley, excessive end play in motor shaft or loose drive belts	Check flywheel, motor pulley, crankshaft drive belt tension/alignment. Replace or repair as required.
M.) Leaking check valve or check valve seat blown out	Replace check valve.
N.) Clogged or dirty inlet and/or discharge line	Clean or replace.
O.) Defective safety/relief valve	Replace.
P.) Pressure switch unloader leaks or does not work	Realign stem or replace.
Q.) Inadequate ventilation around flywheel	Relocate compressor for better air flow.
R.) Leaking, broken or worn inlet unloader parts at check valve	Inspect parts and replace as required.
S.) Excessive condensation in receiver tank	Drain receiver tank.
T.) Detergent lubricant in crankcase.	Replace with proper lubricant.
U.) Light duty cycle	Increase duty cycle.
V.) Lubricant level too high	Drain excess lubricant.
W.) Worn cylinder finish	Deglaze cylinder with 180 grit flex-hone.
X.) Low pressure inlet valve leaking	Inspect, clean or repair as required.
Y.) High pressure inlet valve leaking	Inspect, clean or repair as required.

Parts Explosions – Model 459232 & 459242 Rev P





Fig05833

Parts List – Model 459232 & 459242 Rev P

Ref#	Part#	Description	Model	Qty	Ref#	Part#	Description	Model	Qty
1	788040	Manual Tube (Not Shown)	459232	1	26	34744	¼" NPT Bulkhead Fitting	All	1
2	34937	½" Compression Elbow	459232	1	27	35413	Drain Plug, ¼" NPT	All	1
3	34724	5/8" Compression Long Nut	All	2	28	35406	¼" NPT, ¼" Plastic Tube, Swivel	All	1
4	34723	5/8" Compression Sleeve	All	2	29	34746	¼" Plastic Tube, 1200PSI	All	10.5"
5	792119	Unloader Tube	459232	1	30	34745	¼" NPT ¼" Tube Connection, Brass	All	1
	792118		459242	1	31	789000	NorthStar Label	All	1
6	34750	Bushing, 1 1/8"	All	1	32	794876	80 Gallon Tank	All	1
7	35621	Sheave, AK49H	459232	1	33	792617	½" NPT Elbow, Steel	All	1
	791528	Sheave, 2BK57H	459242	1	34	34733	Ball Valve, ½" NPT	All	1
8	305279	Wire Nut	459232	2	35	789001	Round Pump Label	All	1
	35408	Wire Nut	459242	2	36	4593000	Air Compressor Pump	459232	1
9	795081	5HP DP Electric Motor	459232	1		4593100	Air Compressor Pump	459242	1
	795039	7.5HP Motor	459242	1	37	794233	MC Bracket	459242	1
10	34759	Strain Relief	459232	1	38	34758	Strain Relief, Right Angle	459242	1
	35416	Strain Relief	459242	1	42	35387	Fuse Holder	459242	1
11	795083	12-3 SOOW Cord Assembly	459232	1	43	35386	Fuse	459242	2
	794464	8-3 SOOW Cord Assembly	459242	1	45	794466	Wire Assembly (B2)	459242	1
12	777255	¾" NPT x 5/8" Compression Elbow	459232	1	46	794467	Wire Assembly (R2)	459242	1
	777255	¾" NPT x 5/8" Compression Elbow	459242	2	47	797068	Motor Starter	459242	1
13	36107	¾" Long Brass Adapter	All	1	48	32754	Grounding Post	459242	1
14	792669	¼" Copper Tube, Pressure Switch	All	1	51	35416	Strain Relief	459242	1
15	34740	¼" Compression Long Nut	All	1	52	788565	Belt, A58	459232	1
16	34737	¼" Compression Sleeve Brass	All	1		791550	Belt, B65	459242	2
17	34741	1/8"NPT, ¼" Compression, Brass	All	1	53	788710	Guard Bracket, 5HP	459232	1
18	777221	Check Valve, ¾" NPT	All	1		788709	Guard Bracket, 7.5HP	459242	1
19	35417	Dome Cap	459242	1	54	799800	Belt Guard	All	1
20	35121	Safety Valve, ¾" NPT	All	1	55	798580	Belt Guard Cover	All	1
21	795952	Pressure Switch W/overload	459232	1	56	794465	12-3 SOOW Cord	459242	1
	792606	Pressure Switch	459242	1	57	82720	5/16 Short Extruded U Nut	All	10
22	782705	Reducer ½" NPT X ¼" NPT	All	1					
23	792618	¼" NPT Hex T, Steel	All	1					
24	34699	200 PSI Gauge Liquid Filled	All	1					
25	34759	Strain Relief, Right Angle	All	1					

459232 Pump Explosion



459232 Pump Parts List

Ref#	Part#	Description	Qty	Kit #
1	N/A	Cylinder head	3	Kit # 1
2	N/A	Allen bolt set	12	
3	789354	Air filter *	2	N/A
4	789355	Filter element	2	N/A
5	N/A	Cylinder head gasket	3	Kit # 2
6	N/A	In.& ex. valve assembly	2	Kit # 3
7	N/A	Valve seat gasket	2	Kit # 2
8	N/A	Double head screw set	12	Kit # 4
9	N/A	Cylinder	2	Kit # 5
10	N/A	Cylinder gasket	3	Kit # 2, 5, 6, 9
11	N/A	Piston ring	2	Kit # 5, 6
12	N/A	Piston	2	Kit # 5
13	N/A	Rod	1	N/A
14	N/A	Crankcase	1	N/A
15	789384	Oil draining plug	1	N/A
16	N/A	Front cover gasket	1	Kit # 2
17	N/A	Front cover	1	N/A
18	N/A	Bolt M6 x 20	8	N/A
19	789427	Oil sight gauge	1	N/A
20	789386	Oil filling plug	1	N/A
21	N/A	Bearing	1	N/A
22	N/A	Crankshaft and balancer	1	N/A
23	N/A	Pulley Key	1	N/A
24	N/A	Bearing	1	N/A
25	N/A	Rear bearing seat gasket	1	Kit # 2
26	N/A	Rear bearing seat	1	N/A
27	N/A	Oil seal	1	Kit # 2
28	788882	Breathing cover	1	N/A
29	789365	Pulley	1	N/A
30	N/A	Plate washer	1	Kit # 7
31	N/A	Hexagon bolt	1	
32	N/A	Rod	1	N/A
33	N/A	Exhaust elbow	1	Kit # 8
34	N/A	Exhaust three way pipe	1	
35	789369	Exhaust tube set	1	N/A
36	789370	Exhaust tube set	1	N/A
37	N/A	In.& ex. valve assembly	1	Kit # 3
38	N/A	Valve seat gasket	1	Kit # 2
39	N/A	Cylinder	1	Kit # 9
40	N/A	Piston ring	1	Kit # 6, 9
41	N/A	Piston	1	Kit # 9
42	N/A	Nipple	1	Kit # 10
43	789396	Pressure relief valve	1	N/A
44	N/A	Plug	1	Kit # 10
45	N/A	Intercooler	1	
46	N/A	Exhaust elbow	1	
*	789524	Wing nut, air filter	2	N/A

459232 Pump Kits

Kit # 1 - Cylinder Head Kit- Part # 789336

Ref#	Description	Qty	Kit Qty
1	Cylinder head	1	2
2	Allen bolt set	4	

Kit # 2 – Gasket Seal Kit- Part # 789356

Ref#	Description	Qty	Kit Qty
5	Cylinder head gasket	2	1
7	Valve seat gasket	2	
10	Cylinder gasket	2	
16	Front cover gasket	1	
25	Rear bearing seat gasket	1	
27	Oil seal	1	
38	Valve seat gasket	1	

Kit # 3 – Valve Kit- Part # 789357

Ref#	Description	Qty	Kit Qty
6	In.& ex. valve assembly	2	1
37	In.& ex. valve assembly	1	

Kit # 4 – Screw Kit- Part # 789358

Ref#	Description	Qty	Kit Qty
8	Double head screw set	4	2

Kit # 5 – Cylinder and Piston Kit- Part # 789342

Ref#	Description	Qty	Kit Qty
9	Cylinder	1	2
10	Cylinder gasket	1	
11	Piston ring	1	
12	Piston	1	

Kit # 6 – Piston Ring Kit- Part # 789360

Ref#	Description	Qty	Kit Qty
10	Cylinder gasket	2	1
11	Piston ring	2	
40	Piston ring	1	

Kit # 7 – Plate and Bolt Kit- Part # 789367

Ref#	Description	Qty	Kit Qty
30	Plate washer	1	1
31	Hexagon bolt	1	

Kit # 8 – Elbow and Pipe Kit-Part # 789368

Ref#	Description	Qty	Kit Qty
33	Exhaust elbow	1	1
34	Exhaust three way pipe	1	


Kit # 9 – Cylinder and Piston Kit- Part # 789371

Ref#	Description	Qty	Kit Qty
10	Cylinder gasket	1	1
39	Cylinder	1	
40	Piston ring	1	
41	Piston	1	


Kit # 10 – Intercooler Kit- Part # 789372

Ref#	Description	Qty	Kit Qty
42	Nipple	1	1
44	Plug	1	
45	Intercooler	1	
46	Exhaust elbow	1	

459232 Pneumatic Schematic



459242 Pump Explosion



459242 Pump Parts List

Ref#	Part#	Description	Qty	Kit #
1	N/A	Cylinder head	1	Kit # 1
2	N/A	Allen bolt set	4	
3	N/A	Allen bolt set	1	
4	789375	Air filter *	1	N/A
5	789376	Filter element	1	N/A
6	N/A	Cylinder head gasket	1	Kit # 2
7	N/A	In.& ex. valve assembly	1	Kit # 3
8	N/A	Valve seat gasket	1	Kit # 2
9	N/A	Double head screw set	8	Kit # 4
10	N/A	Cylinder	1	Kit # 5
11	N/A	Cylinder gasket	2	Kit # 2, 5, 7
12	N/A	Piston ring	1	Kit # 5, 7
13	N/A	Piston	1	Kit # 5
14	N/A	Rod	1	Kit # 6
15	789383	Rod bush	2	N/A
16	N/A	Crankcase	1	N/A
17	789384	Oil draining plug	1	N/A
18	N/A	Front bearing seat gasket	1	Kit # 2
19	N/A	Oil mesh	1	N/A
20	N/A	Front bearing seat	1	N/A
21	N/A	Bolt M8 x 25	10	N/A
22	789427	Oil sight gauge	1	N/A
23	789386	Oil filling plug	1	N/A
24	789387	Bearing	2	N/A
25	N/A	Crankshaft and balancer	1	N/A
26	789388	Pulley key	1	N/A
27	N/A	Rear bearing seat gasket	1	Kit # 2
28	N/A	Rear bearing seat	1	N/A
29	788882	Breathing cover	1	N/A
30	N/A	Oil seal	1	Kit # 2
31	791196	Pulley	1	N/A
32	N/A	Plate washer	1	Kit # 8
33	N/A	Bolt M12 x 50	1	
34	N/A	Cylinder head	1	Kit # 9
35	N/A	Allen bolt set	4	
36	N/A	Cylinder head gasket	1	Kit # 2
37	N/A	In.& ex. valve assembly	1	Kit # 3
38	N/A	Valve seat gasket	1	Kit # 2
39	N/A	Cylinder	1	Kit # 10
40	N/A	Piston ring	1	Kit # 7, 10
41	N/A	Piston	1	Kit # 10
42	N/A	Rod	1	Kit # 6
43	N/A	Exhaust elbow	1	Kit # 11
44	N/A	Intercooler	1	
45	789396	Pressure relief valve	1	N/A
46	N/A	Exhaust elbow	2	Kit # 11
47	789397	Exhaust tube	1	N/A
*	789524	Wing nut, air filter	1	N/A

459242 Pump Kits

Kit # 1 - Cylinder and Bolt Kit – Part # 789374

Ref#	Description	Qty	Kit Qty
1	Cylinder head	1	1
2	Allen bolt set	4	
3	Allen bolt set	1	

Kit # 2 – Gasket Kit– Part # 789377

Ref#	Description	Qty	Kit Qty
6	Cylinder head gasket	1	1
36	Cylinder head gasket	1	
8	valve seat gasket	1	
38	valve seat gasket	1	
11	cylinder gasket	2	
18	front cover gasket	1	
27	rear bearing seat gasket	1	
30	oil seal	1	

Kit # 3 – Valve Kit– Part # 789378

Ref#	Description	Qty	Kit Qty
7	In.& ex. valve assembly	1	1
37	In.& ex. valve assembly	1	

Kit # 4 – Screw Kit– Part # 789379

Ref#	Description	Qty	Kit Qty
9	Double head screw set	4	2

Kit # 5 – Cylinder and Piston Kit– Part # 789380

Ref#	Description	Qty	Kit Qty
10	Cylinder	1	1
11	Cylinder gasket	1	
12	Piston ring	1	
13	Piston	1	

Kit # 6 – Rod Kit– Part # 789382

Ref#	Description	Qty	Kit Qty
14	Rod	1	1
42	Rod	1	

Kit # 7 – Piston Ring Kit– Part # 789381

Ref#	Description	Qty	Kit Qty
11	Cylinder gasket	2	1
12	Piston ring	1	
40	Piston ring	1	

Kit # 8 – Plate and Bolt Kit– Part # 789392

Ref#	Description	Qty	Kit Qty
32	Plate washer	1	1
33	Hexagon bolt	1	

Kit # 9–Cylinder Head and Bolt Kit–Part # 789393

Ref#	Description	Qty	Kit Qty
34	Cylinder head	1	1
35	Allen Bolt M6 x 40	4	


Kit # 10–Cylinder and Piston Kit– Part # 789394

Ref#	Description	Qty	Kit Qty
39	Cylinder	1	1
40	Piston ring	1	
41	Piston	1	

Kit # 11–Elbow and Intercooler Kit–Part # 789395

Ref#	Description	Qty	Kit Qty
43	Exhaust elbow	1	1
44	Intercooler	1	
46	Exhaust elbow	1	

459242 Pneumatic Schematic



Appendix A: Lubricants and Compatibility

The following table lists materials that are suitable or not recommended for use with synthetic oil. As some oil escapes into the compressed air, all components that come into contact with the air (i.e., piping, filters, hoses, tools, etc.) must be compatible with synthetic oil.

Northern Tool recommends using synthetic oil after the first 50 hour break in period.

Suitable	Not Recommended
Viton®, Teflon®, Epoxy (Glass Filled), Oil Resistant Alkyd, Fluorosilicone, Fluorocarbon, Polysulfide, 2-Component Urethane, Nylon, Delrin®, Celcon®, High Nitrile Rubber (Buna N. NBR more than 36 Acrylonite), Polyurethane, Polyethylene, Epichlorohydrin, Polyacrylate, Melamine, Polypropylene, Baked Phenolics, Epoxy, Modified Alkyds (® indicates trademark of DuPont Corporation)	Neoprene, Natural Rubber, SBR Rubber, Acrylic Paint, Lacquer, Varnish, Polystyrene, PVC, ABS, Polycarbonite, Cellulose Acetate, Latex, EPR, Acrylics, Phenoxy, Polysulfones, Styrene Acrylonitile (San), Butyl

Alternate Lubricants

You may use a petroleum-based lubricant that is premium quality, does not contain detergents, contains only anti-rust, anti-oxidation, and anti-foam agents as additives, has a flashpoint of 440°F (227°C) or higher, and has an auto-ignition point of 650°F (343°C) or higher.

See the petroleum lubricant viscosity table below. The table is intended as a general guide only. Heavy-duty operating conditions require heavier viscosities.

Refer specific operating conditions to NorthStar Product Support at 1-800-270-0810.

Temperature around Compressor	Viscosity Grade	
	ISO	SAE
Below 40°F (4°C)	60	20
40°F to 80°F (4°C to 27°C)	100	30
80°F to 100°F (27°C to 38°C)	150	40

Limited Warranty

Dear Valued Customer:

The NorthStar Product you just purchased is built with the finest material and craftsmanship. Use this product properly and enjoy the benefits from its high performance. By purchasing a NorthStar product, you show a desire for quality and durability. Like all mechanical equipment this unit requires a due amount of care. Treat this unit like the high quality piece of machinery it is. Neglect and improper handling may impair its performance. Please thoroughly read the instructions and understand the operation before using your product. Always contact NorthStar Product Support at 1-800-270-0810 prior to having any service or warranty work performed, as some services performed by parties other than NorthStar approved service centers may void this warranty. This warranty is in lieu of any other warranty expressed or implied and NorthStar assumes no other responsibility or liability outside that expressed within this warranty.

Limited Warranty

NorthStar shall warranty any piece of equipment manufactured, or parts of equipment manufactured, to be free from defects in material or workmanship for a period of:

NorthStar Warranty		
Item #	Consumer Warranty Period	Commercial Warranty Period
459232	4 years from date of purchase by user	2 years from date of purchase by user
459242		

“Consumer use” means personal residential household use by a consumer. “Commercial use” means all other uses, including use for commercial, income producing or rental purposes or when purchased by a business.

This warranty applies to the original purchaser of the equipment (verification of purchase, in the form of a receipt, is the responsibility of the buyer), is non-transferable, and covers parts and labor. Parts will be replaced or repaired at no charge, except when the equipment has failed due to lack of proper maintenance. If a part is no longer available, the part may be replaced with a similar part of equal function. Any misuse, abuse, alteration or improper installation or operations will void warranty. Determining whether a part is to be replaced or repaired is the sole decision of NorthStar. NorthStar will not provide for replacement of complete products due to defective parts. Any costs incurred due to replacement or repair of items outside of a NorthStar approved facility is the responsibility of the buyer and not covered under warranty. Transportation costs to and from service center is the responsibility of the customer.

In addition to the normal warranty, NorthStar shall warrant any normal wear item from defects in material or workmanship for a period of 90 days from the date of purchase by user. Normal wear items include, but are not limited to, belts and filter elements.

This warranty specifically excludes the following; failure of parts due to damage caused by accident, fire, flood, windstorm, acts of God, applications not approved by NorthStar in writing, corrosion caused by chemicals, use of replacement parts which do not conform to manufacturer’s specifications, damage related to rodent and/or insect infestation and damage caused by vandalism. Additional exclusions: loss of running time, inconvenience, loss of income, or loss of use, including any implied warranty of merchantability of fitness for a specific use. Also, Power Equipment needs periodic parts and service to perform well, and this warranty does not cover instances when normal use has exhausted the life of a component or the motor.

This warranty does not cover any personal injury or damage to surrounding property caused by failure of any part. Repair or replacement of parts does not extend the warranty period.

Please fill in the following information and have it on hand when you call in on a warranty claim.

Customer Number: _____

Date of Purchase: _____

NorthStar Serial Number: _____

Item Number: _____

⚠ WARNING: This product can expose you to soots, tars, and mineral oils (untreated and mildly treated oils and used engine oils), which are known to the State of California to cause cancer.

For more information go to www.P65Warnings.ca.gov.



Assembled by
Northern Tool & Equipment Company, Inc.
Burnsville, MN 55306
NorthernTool.com